





# ANI-PiP-4xUHD SERIES




Connection via RS-232



Selection of Multiview options with fixed Size and Location



PiP with user defined image Size and Location



EDID management, Factory Reset and Firmware update interface

Download available for the  
**4K60 Multi-Viewer Controller\_1.0.5.exe**  
 under the download tab.